

Check	MANUAL DIY KIT BATH BOMB
	Manual + checklist
	Sodium Bicarbonate - ZOU06 - 1 kg (2 units)
	Citric acid - GBB02 - 500 g (1 parts)
	Fragrance oil of choice - 10 ml → choice 1:.....
	Fragrance oil of choice - 10 ml → choice 2:.....
	Cosmetic colorant on water base of choice - 10 ml → choice 1:.....
	Cosmetic colorant on water base of choice - 10 ml → choice 2:.....
	Demineralized water spray - 100 ml (binder)
	2 parts bath bomb molds of choice → choice:.....

Materials

- Sodium bicarbonate (2 units)
- Citric acid (1 part)
- Fragrance oil or essential oil
- Colorant
- Demineralized water spray (binder)
- Mixing bowl (not included)
- Bath bomb molds



Manual

- Put the ingredients together in a bowl and mix well.
- Add fragrance and colorant to your own preference.
- Mix again until you have a uniform mixture.
- Moisten the mixture with demineralized water (binder).
- The mixture must remain one whole. Test this by squeezing it in your hand. If it still falls apart, more binder must be sprayed.
- Repeat until the mixture sticks together.



- Fill both parts with the mixture and press lightly.
- Sprinkle a little bit of the mixture on top.
- Bring the two parts together and press firmly.
- If necessary, correct the outline of the mold by replacing carefully.
- Directly remove one half of the mold.
- Now carefully drop the bath bomb in your hand palm.
- Place the bath bomb on fat-resistant baking paper and let dry for 24/48 hours.
- The final product can best be kept in an airtight, moisture-free box or wrapped in cellophane.
- **Use in a hot bath and let it fade up!**

